

POCKET SCALE

MH-Series
Pocket Scale

STANDARD FEATURES

- *Calibration: Auto Calibration
- *Tare Range: Tare full Capacity
- *Auto off(default): 30 seconds off
- *Operation temperature: 10-30°C
- *Storage temperature: 0-50°C

